



Duplex Wireless System

BATTERY CHARGING

- + System includes rechargeable batteries.
- + Plug charger AC adapter into charging base and into wall outlet.

IMPORTANT: There are two AC adapters supplied with this system. The Com-Center adapter will fit ONLY the Com-Center.

The Charger adapter will fit ONLY the Charger.

- + Batteries should snap into charging slot securely.
- + Charge time 2 - 4 hours.

LED Indicators:

- GREEN: Fully charged
- RED: Charging
- RED Flashing: Battery Faulty
- NO LIGHT: Battery improperly inserted

Charge up to 8
Headset
batteries



Charge up to 2
Com-Center
batteries

BATTERY FACTS

- + COMSTAR high capacity Lithium batteries provide up to 10 hours of operation.
- + Lithium batteries do not develop a memory, so do not need to be drained after use.

IMPORTANT TIPS

Microphone Placement

- + COMSTAR headsets include a special noise cancelling microphone. For optimum performance place directly in front of, and approximately 1 - 2" from the user's mouth.



Com-Center Placement

- + Line of sight: for optimum range, position the Com-Center so that the radio signals have a clear path to the wireless headset/radios.

Storage

- + Lithium batteries should be at least partially charged when stored for long periods.

CAUTION

Compartment on bottom of Com-Center houses switches for factory programming. Call Eartec for more information: 1-800-399-5994.



EARTEC[®]

145 Dean Knauss Drive
Narragansett, RI 02882
Tel: 1-800-399-5994
In RI: 401-782-4966
Fax: 401-789-7300
www.eartec.com